

# **HYPERPRO** *Racing Shock* TYPE 460/461

## **INSTRUCTION SHEET BMW R18 2020> BM18-0AA / BM18-1AA (also with optional preload)**



- Place the bike on the center stand or lift the bike and remove the current shock absorber .
- Place the Hyperpro shock in the bike.
- The adjuster knob of the (optional) HPA on the shock must be facing to the right hand side of the bike.
- Reservoir is facing the left hand side
- Place the bracket between the footrest bolt and footrest
- Make sure the hose is not obstructed.

# **HYPERPRO** *Racing Shock* TYPE 460/461



- Tighten all the bolts with the correct torque (see bike manual)

## **ADDED HARDWARE 461 Reservoir mounting :**

Bolt M6x12 BH	2 pcs.
Bracket 3D-BR-00-075	1 pc.
Clamp 3D-00-60-517AS	1 pc.
Tie wrap L 150	1 pc.

# **HYPERPRO** *Racing Shock* TYPE 460/461



- Remove the side cover to slide the HPA adjuster knob through.
- Route the hose between the frame and the side cover, as shown.
- Make sure the hose is not obstructed.

## **ADDED HARDWARE 460/461 HPA mounting :**

Bolt M6x25	2 pcs
Washer M6	4 pcs
Nyloc nut M6	2 pcs
Bracket 3D-BR-00-074	1 pc.
Tie wrap L 150	1 pc.