

Oktober 2009

Oktober 2009

DE20080314



Anleitung:
Lackscheuerschutz Heckteil Carbon
BMW F800R/S/ST

Lieferumfang:

- 1 x Protektor rechts (A)
- 1 x Protektor links (B)
- 1 x Tube Silikon

Achtung! Wichtige Hinweise

Alle Schraubverbindungen nach 50Km kontrollieren und nachziehen!
Alle Teile vor der Montage sorgfältig entfetten!
Kontrollieren Sie bitte von Zeit zu Zeit den Sitz der Protektoren!

Montage:

1. Entfetten und reinigen Sie alle Teile sorgfältig
2. Bestreichen Sie die Innenseiten der Protektoren mit dem mitgelieferten Silikon
3. Drücken Sie die Protektoren sorgfältig fest. Achten Sie darauf, dass alle Kanten sauber anliegen! Anschließend die Protektoren unter Druck mindestens 12 Stunden fixieren, z. B. mittels Klebeband!

Instruction:
Paint protection for tail sections
carbon BMW F800R/S/ST

Contents:

- 1 x guard right
- 1 x guard left
- 1 x tube silicone

Attention: important tips, explanations

Check all screws after 50Km and retighten if necessary!
Degrease all parts carefully before the assembly!
Check adhesion of the guards in regular intervals.

Assembly:

1. Clean and degrease all parts carefully
2. Apply silicone on the innerside of the Cover guards
3. Press in the guards carefully against the side lids. Make sure, that all edges fit! The cover guards have to be fixed under pressure for 12 hours with adhesive strips, for example!

