

Anleitung:
Blende Radabdeckung BMW R 11XX GS

Lieferumfang:

- 1x Blende Radabdeckung
- 2x Linsenkopfschraube M6
- 2x U-Scheibe M6
- 1x Linsenkopfschraube M5
- 1x U-Scheibe M5

Achtung!
Wichtige Hinweise:

Alle Schraubverbindungen nach 50Km kontrollieren und nachziehen! Drehmomente müssen eingehalten werden.

Montage:

1. Entfernen Sie die Hinterradabdeckung und verschrauben Sie die Blende an den beiden am Kardan angegossenen Gewinden mit den beiliegenden M6 Schrauben und jeweils einer U-Scheibe.
2. Verschließen Sie das offene Gewinde am Kardan mit der U-Scheibe und Schraube M5.

Installation Instruction:
Fender cover BMW R 11XX GS

Contents:

- 1 x Fender cover
- 2 x Screw dome head M6
- 2 x Washer M6
- 1 x Screw dome head M5
- 1 x Washer M5

Attention:

important tips, explanations: Check all screws after 50Km/30miles and retighten if necessary! Follow specs for fastener torques!

Assembly

- 1.) Remove the original rear wheel cover and fix the fender cover with the supplied dome head screws M6 and washers M6
- 2.) Seal the open thread at the cardan with screw M5 and washer.

