

01-048-0155-0

DE20070122

November2007

November2007

1



Anleitung: Rahmenschutz BZ Alu
BMW F650(Twin)/800GS

Instruction: Frame protector BZ Alu
BMW F650(Twin)/800GS

Lieferumfang:

1 x Rahmenschutz
2 x Linsenkopfschraube M6x35
2 x Distanz Alu
2 x U-Scheibe M6 klein

Contents:

1 x frame protector
2 x dome head screw M6x35
2 x spacer aluminium
2 x washer M6 small

Achtung! Wichtige Hinweise

Schraubensicherung mittelfest verwenden.

Anzugsmoment max. 10Nm!!!

Montage

1. Entfernen Sie zuerst den originalen Fersenschutz.

2. Den Rahmenschutz wie in Bild 2 Montieren mit:

2 x Distanz Alu
2 x U-Scheibe M6 klein
2 x Linsenkopfschraube M6x35

Distanzen zwischen Bremszylinder und Rahmenschutz !

Attention: important tips, explanations

Use thread locking compound medium!

Maximum Torque 10Nm!

Assembly

1. Remove the original cover and the original screws

2. Attach the frame protector as shown in pic.2 with:

2 x spacer aluminium
2 x washer M6 small
2 x dome head screw M6x35

Spacers between frame protector and brake operating cylinder!

2

