

01-049-0155-0

März 2007

March 2007

DE20070122



1

Anleitung Kotflügelverbreiterung BMW G650 Xchallenge

Lieferumfang:

- 1 x Kotflügelverbreiterung
- 2 x Linsenflanschkopfschraube M5 x 12 V2A
- 2 x U-Scheibe M5 groß V2A
- 2 x Mutter sesi M5 V2A

Achtung! Wichtige Hinweise



2

Montage

1. Kotflügelverbreiterung wie in Bild 1 ansetzen

ACHTUNG! Achten Sie darauf, dass ein optimaler Formschluss zwischen Verbreiterung und Kotflügel besteht, bevor Sie die Löcher bohren! (Bild 2)



3

2. Bohren Sie zwei Löcher mit 5mm Durchmesser in den Kotflügel (Bild 3)



4

3. Befestigen Sie zuletzt die Verbreiterung wie in Bild 4 mit

- 2 x Linsenflanschkopfschraube M5 x 12 V2A
- 2 x U-Scheibe M5 groß V2A
- 2 x Mutter sesi M5 V2A



5

Installation Instruction: Mudguard Extension BMW G650Xchallenge

Contains:

- 1 x Mudguard Extension
- 2 x button head socket screw with flange M5 x 12 Stainless steel
- 2 x washer M5 big stainless steel
- 2 x nut self-securing M5 stainless steel

Attention: important tips, explanations

Installation

1. Place the Mudguard Extension as shown in picture 1

ATTENTION! Make sure, that the form fits, before you drill the holes! (Picture 2)

2. Drill two holes with 5mm diameter into the Mudguard (picture 3)

3. Assemble the Extension as shown in picture 4 with

- 2 x button head socket screw with flange M5 x 12 stainless steel
- 2 x washer M5 big stainless steel
- 2 x nut self-securing M5 stainless steel